

1774/00
5 LITRE

OVEN CLEANER INFORMATION SHEET

USE:

Effectively cleans grease and charred food from ovens and grills.

DIRECTIONS:

PROTECTIVE GLOVES AND GOGGLES MUST BE WORN.

OVENS: Ensure that the oven is switched off. Apply neat product onto all surfaces of a warm oven. Scrub heavy burnt on deposits with a brush/scouring pad if required. Close oven door and leave product to react for 15 minutes. Scrub with a brush/scouring pad then thoroughly rinse off with water and allow to air dry. **HOT PLATES & GRILLS:** Use only where there is a heavy carbon build-up. Ensure that the appliance is switched off. Apply a 50% solutions onto soiled areas, scrub with a brush/scouring pad. Thoroughly rinse and leave to air dry.

TECHNICAL:

State:	Liquid
Colour:	Orange-brown
Odour:	Characteristic odour
Oxidising:	Non-oxidising (by EC criteria)
Solubility in water:	Soluble
Viscosity:	Viscous
Flash point°C:	>70
pH Level:	12

PERSISTENCE AND DEGRADABILITY: Biodegradable.

